



911 Pin-Lock[™]

For Swing Gates

For securing a swing gate operator arm to a gate using a 1/2" pin and a padlock. May be used to meet fire code with Knox[™] padlock for manual release.

Patent Pending

Made In The USA



Step 1

Insert pin up through gate bracket and gate arm



Step 2

Place the block on top of the pin



Step 3

Insert the Knox[™] padlock through the hole



Step 4

Secure the Knox[™] padlock

Manufactured by 911 Pin-Lock, LLC + PO Box 2736 McKinney, TX 75070 + 972-542-5695

www.911pinlock.com + sales@911pinlock.com